

# Thank you for purchasing Cirbic talking watch!

## Instructions to set analog time:

1. To set analog time, please pull B2 crown button
2. Turn it forwards or backwards until the time displayed is correct
3. Push back B2 crown button.

## Instructions to set voice time:

1. To set voice time, please press B3 button (use a toothpick, screwdriver, or another tiny object)
2. After hearing instructions, use B1 button to set correct setting.
3. Press B3 again to go to next instruction.
4. When done, wait 5 seconds and clock will go back to regular mode.



## Troubleshooting:

No voice when pressing B1	<ul style="list-style-type: none"><li>• Watch is in the “sleep” mode. To wake it up, please hold B1 for more than 5 seconds.</li></ul>
Analogue arrows don’t stay in place	<ul style="list-style-type: none"><li>• B2 is not fully pushed in</li><li>• Plastic protection is not removed under B2 crown button (some models only)</li></ul>

If you need more help, please don’t hesitate to email [support@cirbic.com](mailto:support@cirbic.com) or visit [cirbic.com](http://cirbic.com)